

FIG. 1




FIG. 3




FIG. 2




FIG. 4A




FIG. 4B

TEST CASE TABLE					
STRIDE	101	137	173	211	...
TC1	R	W	T	O	...
TC2	Q	R	W	T	...
.
.

FIG. 4C

COMMAND TABLE			
COMMAND	FUNCTION	BUS COMMAND	CORNER CASE
O	NO OP	--	--
Q	GEN_EXT_COMMAND	READ	--
R	GEN_EXT_COMMAND	READ	DIRTY
W	GEN_INT_COMMAND	WRITE	--
T	GEN_INT_COMMAND	FLUSH	--
.	.	.	.
.	.	.	.
.	.	.	.

500






**FIG. 6A****FIG. 6B****FIG. 6C**

FIG. 7

FIG. 8
(PRIOR ART)